

# LG Aria Digital Key Telephone

## 4 Button Quick Reference User Guide (LDP-7004)

FEATURE	INSTRUCTION
<b>MAKE AN INTERNAL CALL</b>	Dial the extension number Ie. "102"
<b>SELECT A LINE</b>	Dial "0"
<b>DIAL THE ATTENDANT</b>	Dial "9"
<b>TRANSFER A CALL</b>	"TRANS/PGM" Ext.No. Hang-up or wait for an answer then hang-up. Or press the DSS button Hang-up (DSS=direct station selection)
<b>CALL PARKING</b>	Dial "TRANS/PGM" 601-619 ( <b>RETRIEVE CALL:</b> dial 601-619) <b>Note:</b> Most features can be accessed via the menu. Press TRANS/PGM scroll up & down by the volume keys. Make your selection by pressing the relevant digits
<b>BGM (Back Ground Music)</b>	"TRANS/PGM" "73" (channel 01-12, 00 to cancel) "Hold/Save"
<b>CALL FORWARD</b>	Dial 554 1=fwd all,2=busy,3=no ans,4=busy/no ans,5=off-net, 6= off-net no ans, 0=follow me (add # for VMIB)
<b>CANCEL FORWARD</b>	554 #
<b>CHANGE INTERCOM MODE</b>	TRANS/PGM 12 1=Hands free, 2=Tone ring, 3=Private mode SAVE
<b>CHANGE RING TONE</b>	TRANS/PGM 11 1-4 HOLD/SAVE.
<b>EXCLUSIVE HOLD</b>	HOLD HOLD
<b>PAGEALL</b>	#00 <b>INTERNAL:</b> dial #5 <b>EXTERNAL:</b> dial #9
<b>PICKUP</b>	** Direct Pickup: *7 Ext.No
<b>LAST NUMBER REDIAL</b>	Press SPEED *
<b>PROGRAM FLEXIBLE BUTTONS</b>	Press "TRANS/PGM", press programmable flexible button, Dial "extension number or a number below", press "HOLD/SAVE", press programmable flexible button <ul style="list-style-type: none"> <li>▪ To Program CONF button "91"</li> <li>▪ To Program DND/FWD button "93"</li> <li>▪ To Program CALL BACK button "92"</li> <li>▪ To Program MUTE button "95"</li> <li>▪ To Program REDIAL button "97"</li> </ul>